

Shock Absorber

Description

A. MERCEDES BENZ TRUCKS/BUSES/LCVS

FRONTSOCK ABSORBER OM SERIES TRUCK
REAR SHOCK ABSORBER OM SERIES TRUCK
REAR SHOCK ABSORBER MINI BUS
FRONT SHOCK ABSORBER MINI BUS
FRONT SHOCK ABSORBER 911 SERIES TRUCK
REAR SHOCK ABSORBER 911 SERIES TRUCK
FRONT SHOCK ABSORBER LCV TRUCK
REAR SHOCK ABSORBER LCV TRUCK
CABIN SHOCK ABSORBER OM SERIES TRUCK
CABIN SHOCK ABSORBER LP TRUCK
CABIN SHOCK ABSORBER LP TRUCK
ACTORSS CABIN FRONT (SPRING FITTED)
ACTORSS CABIN REAR
ACTORSS CHASIS FRONT
ACTORSS CHASIS MIDDLE
ACTORSSD CHASIS REAR

B. VOLVO TRUCKS/BUSES/LCVS

CABIN SHOCK ABSORBER VOLVO
CABIN SHOCK ABSORBER VOLVO
CABIN SHOCK ABSORBER VOLVO
STEERING DAMPER VOLVO F-12
STEERING DAMPER VOLVO FH-12
CHASIS SHOCK ABSORBER VOLVO F-10
CHASIS SHOCK ABSORBER VOLVO F-12
CHASIS SHOCK ABSORBER VOLVO FH-10
CABIN ABSORBER VOLVO F-10/F-12
CABIN SHOCK ABSORBER VOLVO F-12
CABIN SHOCK ABSORBER VOLVO
CABIN SHOCK ABSORBER VOLVO
FRONT SHOCK ABSORBER LIGHT TRUCK
REAR SHOCK ABSORBER LIGHT TRUCK
REAR CHASIS VOLVO F-16

C. LAND ROVER MPV

REAR SHOCK ABSORBER 110" (H.D)
FRONT SHOCK ABSORBER 110" (H.D)

STEERING DAMPER 110"
FRONT SHOCK ABSORBER 109" (H.D)
REAR SHOCK ABSORBER 109"

D. SCANNIA TRUCK CABIN

CABIN SCANNIA
CABIN SCANNIA
CABIN SCANNIA
CABIN SCANNIA
CABIN SCANNIA
CABIN SCANNIA

E. NISSAN TRUCKS

CABIN SHOCK ABSORBER
NISSAN UD TRUCK REAR
NISSAN HINO TRUCK REAR

OEM Ref .

002 326 2000
002 326 2100
002 323 7200
001 323 5100
002 323 4400
002 323 4500
314 323 0700
001 326 8800
001 891 2205
000 891 0305
000 891 0205

3198859
3198836
3198849
2696003
3373499
1629405
1629477
20374546
1622085
1588043
1580389
1505892
1609603
1689993
1629405

P7851
P7849

T 4006
P 7000
P 7001

1 363 122
1 340 381
1 348 477
1 397 396
1 382 262
1 397 398

98245-007
56101-2
48500-1730